



NOTES:

1. KEEP ALL THREE CONCRETE ANCHORS AS VERTICAL AND AS LEVEL AS POSSIBLE DURING INSTALLATION
2. DRILL WITH 3/4 INCH CEMENT DRILL
3. TORQUE TO SET ANCHOR WEDGE = 110 FT*LBS



39070
CONCRETE ANCHOR KIT FOR UTBASE

© 2013 CAMPBELL SCIENTIFIC, INC.
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
CAMPBELL SCIENTIFIC, INC. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
CAMPBELL SCIENTIFIC, INC. IS PROHIBITED.

SCALE 1:1.5

UNITS: $\frac{\text{IN}}{[\text{MM}]}$

2/1/2021