

# INSTRUCTION MANUAL



## *Model 223 Delmhorst Cylindrical Soil Moisture Block*

Revision: 8/99

Copyright (c) 1991-1999  
Campbell Scientific, Inc.

# **Warranty and Assistance**

---

The **MODEL 223 DELMHORST CYLINDRICAL SOIL MOISTURE BLOCK** is warranted by CAMPBELL SCIENTIFIC, INC. to be free from defects in materials and workmanship under normal use and service for twelve (12) months from date of shipment unless specified otherwise. Batteries have no warranty. CAMPBELL SCIENTIFIC, INC.'s obligation under this warranty is limited to repairing or replacing (at CAMPBELL SCIENTIFIC, INC.'s option) defective products. The customer shall assume all costs of removing, reinstalling, and shipping defective products to CAMPBELL SCIENTIFIC, INC. CAMPBELL SCIENTIFIC, INC. will return such products by surface carrier prepaid. This warranty shall not apply to any CAMPBELL SCIENTIFIC, INC. products which have been subjected to modification, misuse, neglect, accidents of nature, or shipping damage. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose. CAMPBELL SCIENTIFIC, INC. is not liable for special, indirect, incidental, or consequential damages.

Products may not be returned without prior authorization. The following contact information is for US and International customers residing in countries served by Campbell Scientific, Inc. directly. Affiliate companies handle repairs for customers within their territories. Please visit [www.campbellsci.com](http://www.campbellsci.com) to determine which Campbell Scientific company serves your country. To obtain a Returned Materials Authorization (RMA), contact CAMPBELL SCIENTIFIC, INC., phone (435) 753-2342. After an applications engineer determines the nature of the problem, an RMA number will be issued. Please write this number clearly on the outside of the shipping container. CAMPBELL SCIENTIFIC's shipping address is:

**CAMPBELL SCIENTIFIC, INC.**

RMA# \_\_\_\_\_

815 West 1800 North

Logan, Utah 84321-1784

CAMPBELL SCIENTIFIC, INC. does not accept collect calls.

# 223 Table of Contents

---

*PDF viewers note: These page numbers refer to the printed version of this document. Use the Adobe Acrobat® bookmarks tab for links to specific sections.*

<b>1. General Description</b> .....	1
<b>2. Specifications</b> .....	1
<b>3. Installation</b> .....	2
<b>4. Wiring</b> .....	2
<b>5. Programming</b> .....	3
5.1 Measurement - Instruction 5 .....	3
5.2 Calculate Sensor Resistance - Instruction 59 .....	3
5.3 Calculate Soil Water Potential - Instruction 55.....	5
5.4 Example CR10(X) Program for AM416.....	6
5.5 Example 21X Program.....	9



# Model 223 Delmhorst Cylindrical Soil Moisture Block

---

## 1. General Description

The 223 gypsum soil moisture block is configured for use with the AM32 and AM416 Multiplexer. The -L option on the Model 223-L indicates that the cable length is user specified. This manual refers to the sensor as the 223 and applies to the 223-L as well. The Delmhorst cylindrical block is composed of gypsum cast around two concentric electrodes which confine current flow to the interior of the block, greatly reducing potential ground loops. Gypsum located between the outer electrode and the soil creates a buffer against salts which may affect the electrical conductivity. Individual calibrations are required for accurate readings of soil water potential.

The multiplexer that the 223 is connected to leaves the circuit open when no measurements are being made. This blocks direct current flow from the 223 to datalogger ground and prevents electrolysis from prematurely destroying the sensor.

The 223 should not be connected directly to the datalogger. The 227 Delmhorst soil moisture block is available for direct connection and has capacitors in the cable that block direct current flow.

Gypsum blocks typically last for one to two years. Saline or acidic soils tend to degrade the block, reducing longevity. To maximize longevity, gypsum blocks not used during the winter should be removed from the field. Shallow blocks may become frozen and crack, while blocks located below the frost line may not maintain full contact with the soil. Regardless of depth, blocks left in the field over winter are subject to the corrosive chemistry of the soil.

## 2. Specifications

### Approximate Cylinder Dimensions

Diameter	2.25 cm (0.88")
Length	2.86 cm (1.25")

Material                      Gypsum

Electrode Configuration    Concentric cylinders  
Center electrode              Excitation  
Outer electrode                Ground

Calibration:                    Measurements are affected by soil salinity, including fertilizer salts. Individual calibrations are required for accurate measurement of soil water potential. The soil water potential versus resistance values in Table 2 are "typical" values supplied by Delmhorst Corporation. Neither Delmhorst or Campbell Scientific make any claim as to the accuracy of these values. The calibration equations in Section 4.5

were fit to the values in Table 2 to allow output of an estimated water potential.

### 3. Installation

**NOTE**

The black outer jacket of the cable is Santoprene<sup>®</sup> rubber. This compound was chosen for its resistance to temperature extremes, moisture, and UV degradation. However, this jacket will support combustion in air. It is rated as slow burning when tested according to U.L. 94 H.B. and will pass FMVSS302. Local fire codes may preclude its use inside buildings.

Delmhorst recommends the blocks go through two wetting-drying cycles before installation to improve block uniformity. For each cycle, the blocks should be soaked in water for one hour and allowed to dry.

Soil moisture blocks measure only the moisture they "see", therefore placement is important. Avoid depressions where the water will puddle after a rain. Likewise, don't place the blocks in high spots or near changes in slope unless you are trying to measure the variability created by such differences.

Prior to installation, soak the blocks for two to three minutes. Mix a slurry of soil and water to a creamy consistency and place one or two tablespoons into the installation hole. Insert the block, forcing the slurry to envelope the block. This will insure uniform soil contact. Back fill the hole, tamping lightly at frequent intervals.

### 4. Wiring

The 223 is shown in Figure 3. The leads from the block electrodes are connected directly to the H and L inputs on the AM32 or AM416. The lead from the center electrode (white stripe or solid white) connects to H and the lead from the outer electrode (black) to L. A 1K resistor at the datalogger is used to complete the half bridge measurement.




FIGURE 1

TABLE 1. 223 Wiring		
Color	Function	AM416 or AM32
Black w/ White Stripe or White	Excitation	H
Black	Signal Ground	L

## 5. Programming

When a multiplexer is used, the measurements are placed within a loop. Each pass through the loop the multiplexer is clocked to the next channel and the sensors connected to that channel are measured. With the example AM416 program, two 223 sensors are measured each pass through the loop.

### 5.1 Measurement - Instruction 5

Instruction 5 (P5, AC Half Bridge) is used to excite and measure the 227. Recommended excitation voltages and input ranges are given in Table 2.

### 5.2 Calculate Sensor Resistance - Instruction 59

Instruction 59 (Bridge Transform) is used to output sensor resistance ( $R_s$ ). This Instruction takes the AC Half Bridge output ( $V_s/V_x$ ) and computes sensor resistance as follows:

$$R_s = R_1(X/(1-X))$$

$$\text{where, } X = V_s/V_x.$$

The bridge transform multiplier would normally be 1000, representing the fixed resistor ( $R_1$ ) shown in Figure 1. A bridge multiplier of 1000 produces values of  $R_s$  larger than 6999 Ohms causing the datalogger to overrange when using low resolution. To avoid overranging, a bridge multiplier of 1 should be used to output sensor resistance ( $R_s$ ) in terms of kohms.

**TABLE 2. Excitation and Voltage Ranges**

<u>Datalogger</u>	<u>MV Excitation</u>	<u>Input Range</u>	<u>Full Scale Range</u>
21X	500	14	±500 mV
CR7	500	16	±500 mV
CR10(X)	250	14	±250 mV
CR23X	200	13	±200 mV

**NOTE:** Do not use a slow integration time as sensor polarization errors will occur.

The output from Instruction 5 is the ratio of signal voltage to excitation voltage:

$$V_s/V_x = R_s/(R_s+R_1)$$

where,  $V_s$  = Signal Voltage

$V_x$  = Excitation Voltage

$R_s$  = Sensor Resistance

and,  $R_1$  = Fixed Bridge Resistor.

Table 3 lists typical block resistance at different soil water potentials and the resulting  $V_s/V_x$ . Figure 2 is a plot of  $V_s/V_x$  versus bars. The non-linear relationship of  $V_s/V_x$  to bars precludes computing bars from an average of  $V_s/V_x$ .

**TABLE 3. Typical Soil Water Potential,  
 $R_s$  and  $V_s/V_x$**

<u>BARS</u>	<u><math>R_s</math>(kohms)</u>	<u><math>V_s/V_x</math></u>
0.1	0.060	0.0566
0.2	0.130	0.1150
0.3	0.260	0.2063
0.4	0.370	0.2701
0.5	0.540	0.3506
0.6	0.750	0.4286
0.7	0.860	0.4624
0.8	1.100	0.5238
0.9	1.400	0.5833
1.0	1.700	0.6296
1.5	3.400	0.7727
1.8	4.000	0.8000
2.0	5.000	0.8333
3.0	7.200	0.8780
6.0	12.500	0.9259
10.0	17.000	0.9444
11.0	22.200	0.9569
12.0	22.400	0.9573
13.0	30.000	0.9677
14.0	32.500	0.9701
15.0	35.000	0.9722




FIGURE 2. Polynomial Fit to Typical Block Resistance vs. Water Potential

TABLE 4. Polynomial Coefficients for Converting Sensor Resistance to Bars

$$\text{BARS} = C_0 + C_1(R_S) + C_2(R_S)^2 + C_3(R_S)^3 + C_4(R_S)^4 + C_5(R_S)^5$$

(BARS)	MULT. (R <sub>1</sub> )	C <sub>0</sub>	C <sub>1</sub>	C <sub>2</sub>	C <sub>3</sub>	C <sub>4</sub>	C <sub>5</sub>
0.1-10	0.1	.15836	6.1445	-8.4189	9.2493	-3.1685	.33392

### 5.3 Calculate Soil Water Potential - Instruction 55

The datalogger program can be written to store block resistance or can calculate water potential from a block calibration.

For the typical resistance values listed in Table 2, soil water potential (bars) is calculated from sensor resistance (R<sub>S</sub>) using the 5th order Polynomial Instruction. The non linear relationship of R<sub>S</sub> to bars rules out averaging R<sub>S</sub> directly.

A polynomial to calculate soil water potential was fit to the 0.1 to 10 bar range using a least squares fit. The coefficients used for the 10 bar range require R<sub>S</sub> to be scaled down by a factor of 0.1. This multiplier can be entered in the Bridge Transform Instruction or in Processing Instruction 37.

Table 4 lists the coefficients for the 0.1 to 10 bar polynomial. Table 5 shows errors between from the least-squares polynomial approximation and the typical water potential values.

**NOTE**

Our manuals used to show a separate polynomial for the 0.1 to 2 bar range that had slightly smaller deviations from the typical values over the narrower range. However, the variability between blocks is much greater than the improved fit and does not warrant the more complicated program.

**TABLE 5. Polynomial Error - 10 Bar Range**

<u>BARS</u>	$\underline{V}_s/\underline{V}_x$	$\underline{R}_s$	<u>BARS</u> <u>COMPUTED</u>	<u>ERROR</u>
0.1	0.0566	0.006	0.1949	0.0949
0.2	0.115	0.013	0.2368	0.0368
0.3	0.2063	0.026	0.3126	0.0126
0.4	0.2701	0.037	0.3746	-0.0254
0.5	0.3506	0.054	0.4670	-0.0330
0.6	0.4286	0.075	0.5756	-0.0244
0.7	0.4624	0.086	0.6302	-0.0698
0.8	0.5238	0.11	0.7442	-0.0558
0.9	0.5833	0.14	0.8778	-0.0222
1.0	0.6296	0.17	1.0025	0.0025
1.5	0.7727	0.34	1.5970	0.0970
1.8	0.8000	0.40	1.7834	-0.0166
2	0.8333	0.50	2.0945	0.0945
3	0.8780	0.72	2.8834	-0.1166
6	0.9259	1.25	6.0329	0.0329
10	0.9444	1.70	9.9928	-0.0072

**NOTE: ERROR (BARS) = TABLE 3 VALUES - COMPUTED**

### 5.4 Example CR10(X) Program for AM416




FIGURE 3. Wiring for CR10(X) Example

```

*Table 1 Program
01:      60.0000  Execution Interval (seconds)

01: Do (P86)                                     ;Enable AM416
  1:      41      Set Port 1 High

02: Beginning of Loop (P87)                       ;Start of measurement loop
  1:      0      Delay
  2:      16     Loop Count

03: Do (P86)                                     ;Clock Multiplexer to next channel
  1:      72     Pulse Port 2

04: Step Loop Index (P90)                         ;Step index by 2 each pass through loop
  1:      2      Step

05: AC Half Bridge (P5)                          ;Measure the 2 connected 223 blocks
  1:      2      Reps
  2:      14     250 mV Fast Range ;See Table 2 for other dataloggers
  3:      1      SE Channel
  4:      2      Excite all reps w/Exchan 2
  5:      250    mV Excitation ;See Table 2 for other dataloggers
  6:      1--    Loc [ BlockR_1 ] ;-- >>> advance location by index
  7:      1.0    Mult
  8:      0.0    Offset

06: BR Transform Rf[X/(1-X)] (P59)                ;Calculate resistance from Vs/Vx
  1:      2      Reps
  2:      1--    Loc [ BlockR_1 ]
  3:      1      Multiplier (Rf)

07: End (P95)

08: Do (P86)                                     ;Turn off AM416
  1:      51     Set Port 1 Low

;The following loop checks each block resistance and calculates
;water potential if BlockR < 17 kohms. Because 2 blocks are measured
;with each pass through the previous measurement loop, it is simpler
;to use a separate loop for the calculations.
;Leave out following loop if only recording block resistance.

09: Beginning of Loop (P87)                       ;Loop to calculate water potential
  1:      0      Delay
  2:      32     Loop Count

10: If (X<=>F) (P89)                              ;If Rs < 17, apply polynomial
  1:      1--    X Loc [ BlockR_1 ]
  2:      4      <
  3:      17     F
  4:      30     Then Do

11: Z=X*F (P37)                                   ;Scale Rs for polynomial
  1:      1--    X Loc [ BlockR_1 ]
  2:      .1     F
  3:      33--  Z Loc [ WatPot_1 ]

```

```

12: Polynomial (P55)                                ;Convert Rs to bars with 10 bar polynomial
1:      1      Reps
2:     33--    X Loc [ WatPot_1 ]
3:     33--    F(X) Loc [ WatPot_1 ]
4:      .15836 C0
5:      6.1445 C1
6:     -8.4198 C2
7:      9.2493 C3
8:     -3.1685 C4
9:      .33392 C5

13: Else (P94)                                       ;If Rs > 17 load over range value for potential

14: Z=F (P30)
1:     -99999   F
2:      0      Exponent of 10
3:      33     Z Loc [ WatPot_1 ]

15: End (P95)                                       ;End then do

16: End (P95)                                       ;End loop

17: If time is (P92)                                ;Output Resistance and Water Potential
                                           each Hour
1:      0      Minutes (Seconds --) into a
2:      60     Interval (same units as above)
3:      10     Set Output Flag High (Flag 0)

18: Set Active Storage Area (P80)                  ;Fix the Array ID to 60
1:      1      Final Storage Area 1
2:      60     Array ID

19: Real Time (P77)                                ;Output Day and Hour/Minute
1:      220    Day,Hour/Minute (midnight = 2400)

20: Sample (P70)                                   ;Output resistances and Water Potentials
1:      64     Reps
2:      1      Loc [ BlockR_1 ]
    
```

## 5.5 Example 21X Program




FIGURE 4. Wiring for Example 21X Program

*Table 1 Program			
01:	10	Execution Interval (seconds)	
01:	Set Port (P20)		;Enable AM416
1:	1	Set High	
2:	1	Port Number	
02:	Beginning of Loop (P87)		;Start of measurement loop
1:	0	Delay	
2:	16	Loop Count	
03:	Excitation with Delay (P22)		;Clock Multiplexer to next channel
1:	1	Ex Channel	
2:	1	Delay w/Ex (units = 0.01 sec)	
3:	1	Delay After Ex (units = 0.01 sec)	
4:	5000	mV Excitation	
04:	Step Loop Index (P90)		;Step index by 2 each pass through loop
1:	2	Step	
05:	AC Half Bridge (P5)		;Measure the 2 connected 223 blocks
1:	2	Reps	
2:	14	500 mV Fast Range	;See Table 2 for other dataloggers
3:	1	SE Channel	
4:	2	Excite all reps w/Exchan 2	
5:	500	mV Excitation	;See Table 2 for other dataloggers
6:	1--	Loc [ BlockR_1 ]	; -- >>> advance location by index
7:	1.0	Mult	
8:	0.0	Offset	
06:	BR Transform Rf[X/(1-X)] (P59)		;Calculate resistance from Vs/Vx
1:	2	Reps	
2:	1--	Loc [ BlockR_1 ]	
3:	1.0	Mult (Rf)	
07:	End (P95)		

```

08: Set Port (P20) ;Turn off AM416
   1: 0 Set Low
   2: 1 Port Number

;The following loop checks each block resistance and calculates
;water potential if BlockR < 17 kohms. Because 2 blocks are measured
;with each pass through the previous measurement loop, it is simpler
;to use a separate loop for the calculations.
;Leave out following loop if only recording block resistance.

09: Beginning of Loop (P87) ;Loop to calculate water potential
   1: 0 Delay
   2: 32 Loop Count

10: If (X<=>F) (P89) ;If Rs < 17, apply polynomial
   1: 1-- X Loc [ BlockR_1 ]
   2: 4 <
   3: 17 F
   4: 30 Then Do

11: Z=X*F (P37) ;Scale Rs for polynomial
   1: 1-- X Loc [ BlockR_1 ]
   2: .1 F
   3: 33-- Z Loc [ WatPo_1 ]

12: Polynomial (P55) ;Convert Rs to bars with 10 bar polynomial
   1: 1 Reps
   2: 33-- X Loc [ WatPo_1 ]
   3: 33-- F(X) Loc [ WatPo_1 ]
   4: .15836 C0
   5: 6.1445 C1
   6: -8.4198 C2
   7: 9.2493 C3
   8: -3.1685 C4
   9: .33392 C5

13: Else (P94) ;If Rs > 17 load overrange value for potential

14: Z=F (P30)
   1: -99999 F
   2: 33-- Z Loc [ WatPo_1 ]

15: End (P95) ;End then do

16: End (P95) ;End loop

17: If time is (P92) ;Output Resistance and Water Potential
   ;each Hour
   1: 0 Minutes (Seconds --) into a
   2: 60 Interval (same units as above)
   3: 10 Set Output Flag High (Flag 0)

18: Set Active Storage Area (P80) ;Fix the Array ID to 60
   1: 1 Final Storage Area 1
   2: 60 Array ID

```

19: Real Time (P77)			<i>;Output Day and Hour/Minute</i>
1:	220	Day,Hour/Minute (midnight = 2400)	
20: Sample (P70)			<i>;Output resistances and Water Potentials</i>
1:	64	Reps	<i>;32 reps if not outputting water potential</i>
2:	1	Loc [ BlockR_1 ]	





## **Campbell Scientific Companies**

---

### **Campbell Scientific, Inc. (CSI)**

815 West 1800 North  
Logan, Utah 84321  
UNITED STATES  
www.campbellsci.com  
info@campbellsci.com

### **Campbell Scientific Africa Pty. Ltd. (CSAf)**

PO Box 2450  
Somerset West 7129  
SOUTH AFRICA  
www.csafrica.co.za  
sales@csafrica.co.za

### **Campbell Scientific Australia Pty. Ltd. (CSA)**

PO Box 444  
Thuringowa Central  
QLD 4812 AUSTRALIA  
www.campbellsci.com.au  
info@campbellsci.com.au

### **Campbell Scientific do Brazil Ltda. (CSB)**

Rua Luisa Crapsi Orsi, 15 Butantã  
CEP: 005543-000 São Paulo SP BRAZIL  
www.campbellsci.com.br  
suporte@campbellsci.com.br

### **Campbell Scientific Canada Corp. (CSC)**

11564 - 149th Street NW  
Edmonton, Alberta T5M 1W7  
CANADA  
www.campbellsci.ca  
dataloggers@campbellsci.ca

### **Campbell Scientific Ltd. (CSL)**

Campbell Park  
80 Hathern Road  
Shepshed, Loughborough LE12 9GX  
UNITED KINGDOM  
www.campbellsci.co.uk  
sales@campbellsci.co.uk

### **Campbell Scientific Ltd. (France)**

Miniparc du Verger - Bat. H  
1, rue de Terre Neuve - Les Ulis  
91967 COURTABOEUF CEDEX  
FRANCE  
www.campbellsci.fr  
campbell.scientific@wanadoo.fr

### **Campbell Scientific Spain, S. L.**

Psg. Font 14, local 8  
08013 Barcelona  
SPAIN  
www.campbellsci.es  
info@campbellsci.es